

Technical Details

MATERIAL: Polycarbonate - Clear - 1 mm thick
PPE CAT II
CERTIFICATION: EN 166
ANSI Z87.1

OPTICAL CLASS: 1
MARKINGS:
F - Low energy impact
3 - Liquids (droplets or splashes)

 70 g

50 PCS SET: WVI00023



172 mm H x 351mm L

WVI00022

Technology

Flat face shield compatible for use with the full range of KASK Zenith safety helmets
Easy Click System
Large coverage area to protect the entire face

Visor assembling system



WVI00022
ZEN FACE SHIELD

+



WAC00010
ZEN VISOR CARRIER

+



WAC00009
ADAPTERS FOR ZENITH
VISORS ATTACHMENT

=



Additional informations



GUARANTEE

3 years starting from the purchasing date.

CLEANING

Wash the PPE with a solution of 30°C water and neutral soap using a soft cloth. Air dry without rubbing.

Do not use solvents or other chemicals that could damage the product and shorten its useful life.

The COVID 19 disinfection protocols used in hospitals cannot be used on this PPE.

Respect a 72-hour quarantine period.

Wash the products with soap and water at a maximum of 65°C (Attention, the washing temperature at 65°C is an exceptional measure to be used for the emergency of COVID19 and which shortens the life of the product). Air dry.

WARNING: the effectiveness of this treatment against COVID19 is unknown.

STORAGE

Store in a dry and cool place away from UV rays. When not in use, the helmet should be stored away from direct sunlight and sources of heat and we recommend replacing the visor in its original packaging.

ADHESIVE APPLICATION

Do not apply adhesives, solvents, stickers or paint that do not comply with the manufacturer's specifications. Any alteration or addition that is not provided for may impair the protective function of the visor specifications.

Technical Details

MATERIAL: Polycarbonate - Clear - 1 mm thick
PPE CAT II
CERTIFICATION: EN 166
ANSI Z87.1

OPTICAL CLASS: 1
MARKINGS:
S - Increased robustness
3 - Liquids (droplets or splashes)

 70 g

50 PCS SET: WVI00025



WVI00024

Technology

Face shield compatible for use with the full range of KASK Plasma, Superplasma, HP safety helmets.
Large coverage area to protect the entire face

Visor assembling system



Additional informations



GUARANTEE

3 years starting from the purchasing date.

CLEANING

Wash the PPE with a solution of 30°C water and neutral soap using a soft cloth. Air dry without rubbing.

Do not use solvents or other chemicals that could damage the product and shorten its useful life.

The COVID 19 disinfection protocols used in hospitals cannot be used on this PPE.

Respect a 72-hour quarantine period.

Wash the products with soap and water at a maximum of 65°C (Attention, the washing temperature at 65°C is an exceptional measure to be used for the emergency of COVID19 and which shortens the life of the product). Air dry.

WARNING: the effectiveness of this treatment against COVID19 is unknown.

STORAGE

Store in a dry and cool place away from UV rays. When not in use, the helmet should be stored away from direct sunlight and sources of heat and we recommend replacing the visor in its original packaging.

ADHESIVE APPLICATION

Do not apply adhesives, solvents, stickers or paint that do not comply with the manufacturer's specifications. Any alteration or addition that is not provided for may impair the protective function of the visor specifications.